

SECTION 1

[illegible]

Page No.	Description	Group No.	Code
1	SEAT GROUP, OPERATOR'S	911-0502	3022
2			
3			
4			
5			
6			
7			
8			
9			
10			

Supercedes _____ Superceded By _____


GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS

Group No. 911-06502

INDEX

1-2-4

[illegible]



911-06502 *
SEAT GROUP, OPERATORS
100000000

ITEM	PART NO.	QUAN.	DESCRIPTION
1	L118	2	PIN, COTTER
2	T6GG	4	NUT
3	T6GG16	6	SCREW, CAP
4	W10GA	4	WASHER, FLAT
5	W6GF	6	WASHER, LOCK
6	016-20029	1	VALVE, AIR
7	911-65002	1	MOUNT
8	911-65004	1	PLATE

NOTE: SEE CANOPY GROUP (Page 1-5-1)
 FOR OPERATOR'S SEAT.

LEGEND:

SOLD ONLY AS AN ASSEMBLED UNIT

SOLD ONLY AS A KIT

SOLD AS AN ASSEMBLED UNIT
 SERVICEABLE PARTS OF THIS ASSEMBLY ARE SHOWN
 SEPARATELY UNDER THE ASSEMBLY NUMBER

NOT SOLD AS AN ASSEMBLED UNIT
 SERVICEABLE PARTS OF THIS ASSEMBLY ARE SHOWN
 SEPARATELY UNDER THE ASSEMBLY NUMBER

GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS


911-06502

1-2-4

PAGE 1 of 1

3022

REV. 0 RKA2
BELT, SEAT



NOTE: SEAT BELT MOUNTING BRACKETS TO BE WELDED TO
OPERATOR STATION.

LEGEND: SOLD ONLY AS A KIT OR MATCHED SET
** SERVICEABLE PARTS OF THIS ASSEMBLY ARE SHOWN SEPARATELY UNDER THE ASSEMBLY NUMBER

GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS

911-06502
RKA2

REV. _____

1-2-4

SUPP.

PAGE 1 OF 1b

EFFECTIVE SER

911